Powerbank

37685 / FW1771

Instruction manual



- 1 Power Button
- 2. Power Level Indicators LED1-LED4
- 3. USB-C Input / Output
- 4. Dual USB-A Output

Accessory list:

USB-A to USB-C charging cable X 1

Specifications:

Capacity: 8000mAh@3.7V 29.6Wh USB-C Input: 5V=3A USB-C Output: 5V == 3A USB-A1/A2 Output:5V=2.4A

LED INTRODUCTION




How to check the power level:

- Power level indicator: this portable powerbank has 4 power level indicators which enable you to check the remaining power conveniently.
- You can check the power level by pressing the power button (1), as shown on page 1.

ADDITIONAL INFORMATION

- Do not use the powerbank to charge other devices and charge the powerbank at the same time.
- If you are not using the powerbank, we suggested to disconnect the external AC power adapter or DC cable from the powerbank.
- If the powerbank's output voltage is lower than the rated voltage / working voltage of your charging device. the device might not charge or get fully charged.
- If the powerbank's output voltage is higher than the rated voltage / working voltage of your charging device, and the management system cannot support such situation. This might overcharge your device, damage the powerbank or possibly damage your device.

HOW TO USE



Charge the powerbank with an AC power adapter or PC.



Take the powerbank and your charging cable to charge your device everywhere.



Use the powerbank to charge vour mobile phone.



Use the powerbank to charge your tablet.

1) How to charge the powerbank:

If the powerbank is in a low power state, you should charge it with an external AC charger or a PC's USB port. Use the attached USB-A to USB-C cable to charge the powerbank.

2) How to use the powerbank to charge your device(s), taking an Apple iPhone 8 as an example:

- Use the Apple charging cable like the one included with vour iPhone.
- Connect the USB connector to the powerbank's USB output and connect the Apple connector to your iPhone.
- The powerbank will charge your device automatically after the device is connected. Power level indicators will turn off after 5 seconds

SAFETY INSTRUCTIONS

- Do not throw the powerbank into fire or try to heat it up. In such situations it might burn, explode or release toxic gas.
- Do not connect the positive and the negative poles
- Do not connect the powerbank's output with the powerbank's input.
- Do not store the powerbank with other metallic or magnetic materials.
- Do not try to open or break the powerbank.
- Do not put the powerbank in water or make it wet.
- Do not use the powerbank if you notice it is leaking. heating up, looks out of shape, starts to smell or shows any other signs of a malfunctioning powerbank.
- Do not use the powerbank at higher temperatures than 60 °C. The recommended ambient temperature is hetween 15 °C and 25 °C
- Do not use any chargers other than the charger supplied with the powerbank to charge the powerbank.

The names and contents of toxic and hazardous substances or elements in the product [Made in China]

| Product | | Toxic and Hazardous Substances or Elements | | | | | |
|--------------------|------|--|----|----|--------|-----|------|
| Name | Name | | Hg | Cd | Cr[VI] | PBB | PBDE |
| Portabl Battery | | Х | 0 | 0 | 0 | 0 | 0 |

0: Means (that) the content of this harmful substances in all the parts of homogeneous material is under S/T11363-2006 required standards

X: Means (that) the content of this harmful substances at least in parts of homogeneous material is within S/T11363-2006 required standards

STORAGE AND MAINTENANCE

If you will not use the powerbank for more than 3 months, please proceed according to the instructions below to maintain its normal performance:

- First fully charge the powerbank, then discharge with devices like your phone or tablet, then recharge the powerbank to half its capacity and keep it in a cool and dry place.
- It is recommended to perform a complete charging and discharging cycle every 3 months in order to ensure the best performance of the battery cells inside.



Scan the QR code for the digitial version of this manual.

Made in China / Fahriqué en Chine Hecho en China / Proizvedeno u Kini





© 2019 adidas AG, adidas, le lono trèfle et le logo des

3 bandes sont des marques déposées du groupe adidas.

© 2019 adidas AG, adidas, the Trefoil loop and the 3-Strines mark are registrated trademarks of the adidas Group.

Telecom Lifestyle Fashion B.V. | The Netherlands Made under license from adidas AG. Telecom Lifestyle Fashion B.V. | Les Pays-Bas Fabriqué sous licence d'adidas AG.











