





USER MANUAL




GRIP & STAND USAGE

1. OPEN THE BAND BY PULLING THE TOP OF THE 'CLOSED' STRAP AS SHOWN.
2. YOUR STRAP IS NOW IN AN 'OPEN' POSITION.
3. FOLD THE STRAP AS SHOWN AND PRESS BOTH SIDES UNTIL THEY SNAP. YOUR STRAP IS NOW IN 'STAND' FUNCTION.



GRIP FUNCTION

1. START WITH THE GRIP IN 'OPEN' POSITION
2. SLIDE IN YOUR HAND PALM FACING YOUR PHONE. THE GRIP SHOULD BE PLACED WITHIN THE MARKED AREA.*
3. HOLD NATURALLY FOR A SECURE GRIP DURING YOUR ACTIVITY.



STAND FUNCTION

1. START WITH THE GRIP IN 'STAND' FUNCTION
2. THE GRIP WILL NOW FORM A STEADY VERTICAL 'PORTRAIT' STAND FUNCTION.
3. ROTATE YOUR PHONE FOR A STEADY HORIZONTAL 'LANDSCAPE' STAND FUNCTION.

ADIDAS IS NOT RESPONSIBLE FOR:

- * ANY DAMAGE TO ANY SURFACE CAUSED BY THE USE OR APPLICATION OF THE MAGSAFE STAND & GRIP.
- * ANY DAMAGE TO ANY DEVICE AND DEVICE PROTECTION RESULTING FROM THE INCORRECT USE OF THE MAGSAFE STAND & GRIP.
- * THIS PRODUCT IS ONLY COMPATIBLE WITH MAGSAFE DEVICES AND MAGSAFE CASES.
- * WE ADVISE TO CARRY PHONE AND GRIP TOGETHER. DO NOT CARRY BY GRIP ALONE.
- * PLEASE REMOVE FOR MAGSAFE AND WIRELESS CHARGING.